

LABOND “CORAL FLEXIBLE W889” Cementitious Flexible Waterproofing Coating

立康牌 W889 英泥彈性防水塗漿

<p>Step 1 步驟 1 Any pipes/services though slab/wall must be treated with “Coral Mastic R600” cementitious sealant and allow dry before receiving “Coral 889”. 遇到有過牆身或地台的喉位及有關設施，需先用“Coral R600”彈性英泥膠於其邊位處理一層。</p>	<p>Step 2 步驟 2 A completed treatment with “R600” to water outlet thought wall. 已完成用“R600”處理的過喉位位置。</p>	<p>Step 3 步驟 3 Pour the pre-set liquid part of CORAL FLEXIBLE W889 into a plastic drum. 先將 W889 的液態部份倒進一個預先準備好的膠桶內。</p>	<p>Step 4 步驟 4 Pour the powder part of CORAL FLEXIBLE W889 and mixing immediately with the liquid part by using an electric stirring machine. 然後再將粉劑部份倒進桶內並用手提電攪拌器混合。</p>
			
<p>Step 5 步驟 5 Keep mixing until it become homogenous paste-like mortar. 攪拌直至形成一均衡的膠體狀。</p>	<p>Step 6 步驟 6 Apply 1st coat of CORAL FLEXIBLE W889 by brushing Method. 用油掃施工，先塗上一層。</p>	<p>Step 7 步驟 7 A completed system shall be in two coats with a total thickness of not less than 2mm. 需先後塗上兩層“Coral 889”才算完成，總共厚度需不少於2mm。</p>	
			